

ASSEMBLY INSTRUCTIONS FOR YOUR

**Jonathan Adler**

**CAPRI TABLE LAMP  
SHAPE 1**

**IMPORTANT SAFETY INSTRUCTIONS**

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock, this plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG.**

Turn power to lamp OFF before replacing the bulb, making sure the bulb has had sufficient time to cool down. Do not subject the lamp to any shock while lit as shattering of bulb may result.

**ASSEMBLY INSTRUCTIONS:**

NOTE: Do not connect the electricity until lamp is fully assembled.

1. Remove all parts from carton. Do not throw away any parts.
2. Place base (D) on level surface.
3. Remove socket ring (A) from threaded socket (C).
4. Place shade spider (located inside shade (B)) over threaded socket (C).
5. Thread socket ring (A) onto socket (C) to secure shade (B) to lamp.
6. Install one (1) 150W Max. Type A, bulb into socket (C).
7. Remove protective plastic (F) from polarized plug (E).
8. Insert polarized plug (E) into wall outlet.

\*\* To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners. \*\*

